AIRSTAGE
Service Monitor Tool
INSTALLATION MANUAL

UTY-ASSXZ1

Android

Bluetooth® C E

Complies with
IMDA Standards
DA107974

TDRA

ER28620/24
United Arab Emirates

PART No. 9712633001-01

FUJITSU GENERAL LIMITED
3-3-17, Suenaga, Takatsu-ku, Kawasaki 213-8502, Japan

English

1. APP INSTALLATION

Open "Google Play" and download "AIRSTAGE Service Monitor Tool" (hereinafter called this app). It can also be downloaded from the QR code on the cover.

2. CONNECTION

■ Items required for connection

- Mobile device with this app downloaded
- BLE adapter*
    * Our dedicated communication adapter with Bluetooth Low Energy

BLE adapter

USB cable

LED lamp

■ Connection method

(1) Turn off the power of the outdoor unit.

(2) Connect the BLE adapter to the connector labeled "FLASH" on the outdoor unit control PCB.

There are three types of connectors on the control PCB.

Select the required cable from the following three types:

TYPE1 : PA connector -6 pin

TYPE2 : PA connector -10 pin

TYPE3 : PA connector -12 pin

* When the connection is complete, LED lamp of BLE adapter blinks very quickly. (Twice every 4 seconds)

(3) Pair the BLE adapter with a mobile device.

For the pairing and setting methods, select this app > ⚙ (Settings) > USER'S MANUAL and refer to the user's manual.

Cable for control PCB (TYPE 1/2/3)

BLE adapter

USB cable

Control PCB of outdoor unit